




QUICK START

HOW TO USE

WARNING! Burn Hazard: Always use an oven mitt to protect hand when opening cover.



Plug cord into wall outlet. The red **POWER** light will glow. Let unit preheat with cover closed and cooking plates rotated in between rings. **NOTE:** Green **PREHEAT** light will come on when unit is heated to the correct temperature and will cycle on and off during cooking. It is NOT an indicator when sandwich is ready. Red **POWER** light stays on. Use handles to lift cover, top rings, and cooking plates.



Place bottom half of bread (such as an English muffin, small bagel, or biscuit) onto bottom plates. Top bread with ingredients such as precooked meats, vegetables, and cheese. Move top rings and cooking plates down.

QUICK START

HOW TO USE (cont.)



Crack an egg onto each cooking plate. Pierce yolk with a fork or toothpick. (You can use a whole large egg, egg white, or a scrambled egg.) Top with the other half of bread. Close cover. Cook sandwiches for 4 to 5 minutes. **NOTE:** Do not push lid all the way down when loaded with ingredients or when using a jumbo egg.



Press the up or down button to the desired time in half-minute (0.5) increments. If the up or down button has not been pressed in 5 seconds, the timer will start. When there is less than 1 minute remaining, the timer switches to seconds and continues to count down. The timer will beep when the time is up. Press the up or down button to stop beeping. This unit does not turn off automatically at the beep.



When finished cooking, rotate cooking plate handles out until they stop. Using an oven mitt, lift ring assemblies and cover by holding bottom ring handles to open. Remove breakfast sandwiches with plastic or wooden utensil. Never use metal. Unplug when through cooking. Let cool.